

## YHTEENSOPIVUUSTAULUKKO

**DIGIKAMERA-AKUT 14.04.2010**



**ED-MARK Oy**  
**Vilhonvuorenkatu 11A**  
**00500 HELSINKI**

**Puh 09-682 2420**  
[myynti@ed-mark.fi](mailto:myynti@ed-mark.fi)  
[www.ed-mark.fi](http://www.ed-mark.fi)

**9.4.2010**

**BATTERY - REFERENCE - LIST**



<b>Agfaphoto</b>	DC-533	AA	BRAUN NiMH 2700		
	DC-530i	AA	BRAUN NiMH 2700		
	DC-500	AA	BRAUN NiMH 2700		
	DC-630	AA	BRAUN NiMH 2700		
	DC-630i	AA	BRAUN NiMH 2700		
	DC-630xs	AA	BRAUN NiMH 2700		
	DC-630x	AA	BRAUN NiMH 2700		
	DC-633xs	AA	BRAUN NiMH 2700		
	DC-730i	AA	BRAUN NiMH 2700		
	DC-735	3,7V/750mAh	BDP-FNP40	B10	59209
	DC-830	AA	BRAUN NiMH 2700		
	DC-1030i	AA	BRAUN NiMH 2700		
	DC-8330i	AA	BRAUN NiMH 2700		

<b>Benq</b>	DC-2300	AA	BRAUN NiMH 2700		
	DC-2410	AA	BRAUN NiMH 2700		
	DC-4500	AA	BRAUN NiMH 2700		
	DC-C40	AA	BRAUN NiMH 2700		
	DC-C50	3,7V/1100mAh	BDP-FNP60	B12	59211
	DC-C500	3,7V/720mAh	BDP-MNP900	B104	59314
	DC-C530	AA	BRAUN NiMH 2700		
	DC-C540	AA	BRAUN NiMH 2700		
	DC-C610	AA	BRAUN NiMH 2700		
	DC-C630	AA	BRAUN NiMH 2700		
	DC-C640	AA	BRAUN NiMH 2700		
	DC-C740	AA	BRAUN NiMH 2700		
	DC-C741i	AA	BRAUN NiMH 2700		
	DC-C750	AA	BRAUN NiMH 2700		
	DC-C840	AA	BRAUN NiMH 2700		
	DC-C850	AA	BRAUN NiMH 2700		
	DC-E43	3,7V/720mAh	BDP-MNP900	B104	59314
	DC-E53	3,7V/720mAh	BDP-MNP900	B104	59314
	DC-E310	AA	BRAUN NiMH 2700		
	DC-E510	3,7V/1230mAh	BDP-CNP40	B53	59251
	DC-E520	3,7V/1230mAh	BDP-CNP40	B53	59251
	DC-E600	3,7V/1230mAh	BDP-CNP40	B53	59251
	DC-E610	3,7V/1230mAh	BDP-CNP40	B53	59251
	DC-E720	3,7V/720mAh	BDP-MNP900	B104	59314
	DC-E800	3,7V/710mAh	BDP-FNP40	B10	59209
	DC-E820	3,7V/650mAh	BDP-CNP20	B9	59208
	DC-P860	AA	BRAUN NiMH 2700		
	DC-P500	3,7V/1230mAh	BDP-CNP40	B53	59251
	DC-T700	3,7V/650mAh	BDP-CNP20	B9	59208
	DC-T800	3,7V/650mAh	BDP-CNP20	B9	59208
	DC-X600	3,7V/750mAh	BDP-FNP40	B10	59209
	DC X720	3,7V/650mAh	BDP-CNP20	B9	59208
	DC-X725	3,7V/650mAh	BDP-CNP20	B9	59208

<b>BRAUN</b>	D570	AA	BRAUN NiMH 2700		
	D590	AA	BRAUN NiMH 2700		
	D670	AA	BRAUN NiMH 2700		
	D700	AA	BRAUN NiMH 2700		
	DC72	AA	BRAUN NiMH 2700		
	DC84	AA	BRAUN NiMH 2700		
	DC101	AA	BRAUN NiMH 2700		
	D800	AA	BRAUN NiMH 2700		
	D75i	3,7V/750mAh	BDP-FNP40	B10	59209
	DS83	3,7V/750mAh	BDP-FNP40	B10	59209
	DS101	3,7V/750mAh	BDP-FNP40	B10	59209
	D808	3,7V/750mAh	BDP-FNP40	B10	59209
	D830	3,7V/750mAh	BDP-FNP40	B10	59209
	D905	AA	BRAUN NiMH 2700		

<b>Canon</b>	EOS 1D Mark III	11,1V/2400mAh	BDP-CLPE4	B158	59365
	EOS 1D Mark IV	11,1V/2400mAh	BDP-CLPE4	B158	59365
	EOS 1DS Mark III	11,1V/2400mAh	BDP-CLPE4	B158	59365
	EOS 5D	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS 5D Mark II	7,4V/1500mAh	BDP-CLPE6	B155	59363
	EOS 7D	7,4V/1500mAh	BDP-CLPE6	B155	59363
	EOS D10	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS D30	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS D60	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS 20D	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS 20DA	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS 30D	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS 40D	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS 50D	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS 50D	7,4V/2000mAh	BDP-CBP512	B154	59362
	EOS 300D	7,4V/1620mAh	BDP-BP511	B2	59201
	EOS 350D	7,4V/750mAh	BDP-NB2LH	B4	59203
	EOS 400D	7,4V/750mAh	BDP-NB2LH	B4	59203
	EOS 450D	7,4V/1100mAh	BDP-CLP-E5	B103	59313
	EOS 500D	7,4V/1100mAh	BDP-CLP-E5	B103	59313
	EOS 550D		not Available		
	EOS 1000D	7,4V/1100mAh	BDP-CLP-E5	B103	59313
	IXY Digital 25IS	3,7V/1000mAh	BDP-CNB6L	B135	59343
	IXUS 30	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 40	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 50	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 55	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 60	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 65	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 70	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 75	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 80IS	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 85IS	3,7V/1000mAh	BDP-CNB6L	B135	59343

<b>Canon</b>	IXUS 90IS	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 95IS	3,7V/1000mAh	BDP-CNB6L	B135	59343
	IXUS 100IS	3,7V/720mAh	BDP-NB4L	B6	59205
	<b>IXUS 105</b>	<b>3,7V/1000mAh</b>	<b>BDP-CNB6L</b>	<b>B135</b>	<b>59343</b>
	IXUS 110IS	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS 120SI	3,7V/720mAh	BDP-NB4L	B6	59205
	<b>IXUS 130</b>	<b>3,7V/720mAh</b>	<b>BDP-NB4L</b>	<b>B6</b>	<b>59205</b>
	IXUS 200IS	3,7V/1000mAh	BDP-NB6L	B135	59343
	<b>IXUS 210</b>	<b>3,7V/1000mAh</b>	<b>BDP-NB6L</b>	<b>B135</b>	<b>59343</b>
	IXUS 300	3,7V/1000mAh	BDP-NB1LH	B3	59202
	IXUS 330	3,7V/1000mAh	BDP-NB1LH	B3	59202
	IXUS 400	3,7V/1000mAh	BDP-NB1LH	B3	59202
	IXUS 430	3,7V/1000mAh	BDP-NB1LH	B3	59202
	IXUS 500	3,7V/1000mAh	BDP-NB1LH	B3	59202
	IXUS 700	3,7V/790mAh	BDP-NB-3L	B5	59204
	IXUS 750	3,7V/790mAh	BDP-NB-3L	B5	59204
	IXUS 800IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS 850IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS 860IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS 870IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS 900TI	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS 950 IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS 960IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS 970IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS 980IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS 990IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	IXUS i	3,7V/790mAh	BDP-NB-3L	B5	59204
	IXUS i zoom	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS i5	3,7V/790mAh	BDP-NB-3L	B5	59204
	IXUS i7	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS i7 zoom	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS WIRELESS	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS TX1	3,7V/720mAh	BDP-NB4L	B6	59205
	IXUS V, V2 <sup>2</sup> , V <sup>3</sup>	3,7V/1000mAh	BDP-NB1LH	B3	59202
IXUS II	3,7V/790mAh	BDP-NB-3L	B5	59204	
IXUS Iis	3,7V/790mAh	BDP-NB-3L	B5	59204	
Powershot A 70	AA	BRAUN NiMH 2700			
Powershot A 75	AA	BRAUN NiMH 2700			
Powershot A 80	AA	BRAUN NiMH 2700			
Powershot A 85	AA	BRAUN NiMH 2700			
Powershot A 95	AA	BRAUN NiMH 2700			
Powershot A 410	AA	BRAUN NiMH 2700			
PowerShot A420	AA	BRAUN NiMH 2700			
PowerShot A430	AA	BRAUN NiMH 2700			
PowerShot A450	AA	BRAUN NiMH 2700			
PowerShot A460	AA	BRAUN NiMH 2700			
PowerShot A470	AA	BRAUN NiMH 2700			
PowerShot A480	AA	BRAUN NiMH 2700			
PowerShot A490	AA	BRAUN NiMH 2700			

Canon					
	PowerShot A495	AA	BRAUN NiMH 2700		
	PowerShot A510	AA	BRAUN NiMH 2700		
	PowerShot A520	AA	BRAUN NiMH 2700		
	PowerShot A530	AA	BRAUN NiMH 2700		
	PowerShot A540	AA	BRAUN NiMH 2700		
	PowerShot A550	AA	BRAUN NiMH 2700		
	PowerShot A560	AA	BRAUN NiMH 2700		
	PowerShot A570 IS	AA	BRAUN NiMH 2700		
	PowerShot A580	AA	BRAUN NiMH 2700		
	PowerShot A 590IS	AA	BRAUN NiMH 2700		
	PowerShot A610	AA	BRAUN NiMH 2700		
	PowerShot A620	AA	BRAUN NiMH 2700		
	PowerShot A630	AA	BRAUN NiMH 2700		
	PowerShot A640	AA	BRAUN NiMH 2700		
	PowerShot A650IS	AA	BRAUN NiMH 2700		
	PowerShot A700	AA	BRAUN NiMH 2700		
	PowerShot A710 IS	AA	BRAUN NiMH 2700		
	PowerShot A720 IS	AA	BRAUN NiMH 2700		
	PowerShot A1000IS	AA	BRAUN NiMH 2700		
	PowerShot A1100IS	AA	BRAUN NiMH 2700		
	PowerShot A2000IS	AA	BRAUN NiMH 2700		
	PowerShot A2010IS	3,7V/1000mAh	BDP-CNB6L	B135	59343
	PowerShot A2100IS	AA	BRAUN NiMH 2700		
	PowerShot A3000		not Available		
	PowerShot A3100IS		not Available		
	PowerShot D 10	3,7V/1000mAh	BDP-CNB6L	B135	59343
	PowerShot E1	AA	BRAUN NiMH 2700		
	Powershot G1, G2	7,4V/1620mAh	BDP-BP511	B2	59201
	Powershot G3, G5	7,4V/1620mAh	BDP-BP511	B2	59201
	Powershot G6	7,4V/750mAh	BDP-NB2LH	B4	59203
	Powershot G7	7,4V/750mAh	BDP-NB2LH	B4	59203
	Powershot G9	7,4V/750mAh	BDP-NB2LH	B4	59203
	Powershot G10		not Available		
	Powershot G11		not Available		
	Powershot Pro 1	7,4V/1620mAh	BDP-BP511	B2	59201
	Powershot Pro 70	7,4V/1000mAh	BDP-BP511	B2	59201
	Powershot Pro 90	7,4V/1620mAh	BDP-BP511	B2	59201
	PowerShot S2 IS	AA	BRAUN NiMH 2700		
	PowerShot S3 IS	AA	BRAUN NiMH 2700		
	PowerShot S5 IS	AA	BRAUN NiMH 2700		
	Powershot S30	7,4V/750mAh	BDP-NB2LH		
	Powershot S40, S45	7,4V/750mAh	BDP-NB2LH	B4	59203
	Powershot S50	7,4V/750mAh	BDP-NB2LH	B4	59203
	Powershot S60	7,4V/750mAh	BDP-NB2LH	B4	59203
	Powershot S70	7,4V/750mAh	BDP-NB2LH	B4	59203
	Powershot S80	7,4V/750mAh	BDP-NB2LH	B4	59203
	Powershot S90	3,7V/1000mAh	BDP-NB6L	B135	59343
	Powershot SD770is	AA	BRAUN NiMH 2700		
	PowerShot SX1IS	AA	BRAUN NiMH 2700		
	PowerShot SX10IS	AA	BRAUN NiMH 2700		

<b>Canon</b>	PowerShot SX20IS	AA	BRAUN NiMH 2700		
	PowerShot SX100IS	AA	BRAUN NiMH 2700		
	PowerShot SX110IS	AA	BRAUN NiMH 2700		
	PowerShot SX120IS	AA	BRAUN NiMH 2700		
	PowerShot SX200IS	3,7V/1120mAh	BDP-NB5L	B7	59206
	<b>PowerShot SX210IS</b>	<b>3,7V/1120mAh</b>	<b>BDP-NB5L</b>	<b>B7</b>	<b>59206</b>
	PowerShot TX1	3,7V/720mAh	BDP-NB4L	B6	59205
<b>Casio</b>	Exilim Pro EX-F 1	7,4V/1950mAh	BDP-CNP100	B126	59336
	<b>Exilim E-FH100</b>	<b>3,7V/1700mAh</b>	<b>BDP-CNP90</b>	<b>B164</b>	<b>59372</b>
	Exilim EX-M2	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-P505	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim Hi-Zoom EX-V7S	3,7V/950mAh	BDP-CNP50	B11	59210
	Exilim Hi-Zoom EX-V7B	3,7V/950mAh	BDP-CNP50	B11	59210
	Exilim Pro EX-P505	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim Pro EX-P600	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-FC100	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-FS10	3,7V/720mAh	BDP-CNP60	B101	59311
	Exilim EX-S	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S2	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S3	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S10	3,7V/720mAh	BDP-CNP60	B101	59311
	Exilim EX-S12	3,7V/720mAh	BDP-CNP60	B101	59311
	Exilim EX-S20	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S100	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S500Silver	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S500 Orange	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S500Grey	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S600 Sparkle	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S600 Mistral	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S600 Orange	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S600D	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S770	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S770D	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-S880	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim QV-R3	3,7V/720mAh	BDP-CNP60	B101	59311
	Exilim QV-R4	3,7V/720mAh	BDP-CNP60	B101	59311
	Exilim EX-G1	3,7V/600mAh	BDP-CNP80	B156	59364
	<b>Exilim EX-H10</b>	<b>3,7V/1700mAh</b>	<b>BDP-CNP90</b>	<b>B164</b>	<b>59372</b>
	<b>Exilim EX-H15</b>	<b>3,7V/1700mAh</b>	<b>BDP-CNP90</b>	<b>B164</b>	<b>59372</b>
	Exilim EX-V7	3,7V/950mAh	BDP-CNP50	B11	59210
	Exilim EX-V8	3,7V/950mAh	BDP-CNP50	B11	59210
	Exilim EX-Z1	3,7V/600mAh	BDP-CNP80	B156	59364
<b>Exilim EX-Z2</b>	<b>3,7V/600mAh</b>	<b>BDP-CNP80</b>	<b>B156</b>	<b>59364</b>	
Exilim EX-Z3	3,7V/650mAh	BDP-CNP20	B9	59208	
Exilim EX-Z4	3,7V/650mAh	BDP-CNP20	B9	59208	
Exilim EX-Z5	3,7V/650mAh	BDP-CNP20	B9	59208	
Exilim EX-Z6	3,7V/650mAh	BDP-CNP20	B9	59208	
Exilim EX-Z7	3,7V/650mAh	BDP-CNP20	B9	59208	
Exilim EX-Z8	3,7V/650mAh	BDP-CNP20	B9	59208	
Exilim EX-Z10	AA	BRAUN NiMH 2700			

<b>Casio</b>	Exilim EX-Z11	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-Z12	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-Z20	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-Z21	3,7V/720mAh	BDP-CNP60	B101	59311
	<b>Exilim EX-Z25</b>	<b>3,7V/720mAh</b>	<b>BDP-CNP60</b>	<b>B101</b>	<b>59311</b>
	Exilim EX-Z30	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z40	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z50	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z55	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z57	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-Z60	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-Z65	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-Z70	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-Z75	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-Z77	3,7V/650mAh	BDP-CNP20	B9	59208
	Exilim EX-Z80	3,7V/720mAh	BDP-CNP60	B101	59311
	Exilim EX-Z85	3,7V/720mAh	BDP-CNP60	B101	59311
	Exilim EX-Z90	3,7V/720mAh	BDP-CNP60	B101	59311
	Exilim EX-Z100	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z110	AA	BRAUN NiMH 2700		
	Exilim EX-Z120	AA	BRAUN NiMH 2700		
	Exilim EX-Z150	3,7V/1050mAh	BDP-CNP70	B144	59352
	Exilim EX-Z200	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z250	3,7V/1050mAh	BDP-CNP70	B144	59352
	Exilim EX-Z250BE	3,7V/1050mAh	BDP-CNP70	B144	59352
	Exilim EX-Z250GD	3,7V/1050mAh	BDP-CNP70	B144	59352
	Exilim EX-Z250PK	3,7V/1050mAh	BDP-CNP70	B144	59352
	Exilim EX-Z250RD	3,7V/1050mAh	BDP-CNP70	B144	59352
	Exilim EX-Z250SR	3,7V/1050mAh	BDP-CNP70	B144	59352
	Exilim EX-Z270	3,7V/600mAh	BDP-CNP80	B156	59364
	Exilim EX-Z280	3,7V/600mAh	BDP-CNP80	B156	59364
	Exilim EX-Z300	3,7V/1230mAh	BDP-CNP40	B53	59251
	<b>Exilim EX-Z330</b>	<b>3,7V/600mAh</b>	<b>BDP-CNP80</b>	<b>B156</b>	<b>59364</b>
	Exilim EX-Z400	3,7V/1230mAh	BDP-CNP40	B53	59251
	<b>Exilim EX-Z450</b>	<b>3,7V/1230mAh</b>	<b>BDP-CNP40</b>	<b>B53</b>	<b>59251</b>
	Exilim EX-Z500	3,7V/1230mAh	BDP-CNP40	B53	59251
	<b>Exilim EX-Z550</b>	<b>3,7V/600mAh</b>	<b>BDP-CNP80</b>	<b>B156</b>	<b>59364</b>
	Exilim EX-Z600	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z700	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z750	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z850	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z1000	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z1050	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z1080	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z1200	3,7V/1230mAh	BDP-CNP40	B53	59251
	Exilim EX-Z2000		BDP-CNP110		
	FH 20	AA	BRAUN NiMH 2700		
	GV-10	AA	BRAUN NiMH 2700		
	QV-3EX	AA	BRAUN NiMH 2700		

Casio			
	QV-10A	AA	BRAUN NiMH 2700
	QV-70	AA	BRAUN NiMH 2700
	QV-100	AA	BRAUN NiMH 2700
	QV-300	AA	BRAUN NiMH 2700
	QV-700	AA	BRAUN NiMH 2700
	QV-780	AA	BRAUN NiMH 2700
	QV-2000UX/Ir	AA	BRAUN NiMH 2700
	QV-2300UX	AA	BRAUN NiMH 2700
	QV-2400UX	AA	BRAUN NiMH 2700
	QV-2800UX	AA	BRAUN NiMH 2700
	QV-2900UX	AA	BRAUN NiMH 2700
	QV-3000EX/Ir	AA	BRAUN NiMH 2700
	QV-3500EX	AA	BRAUN NiMH 2700
	QV-4000	AA	BRAUN NiMH 2700
	QV-5000SX	AA	BRAUN NiMH 2700
	QV-5500SX	AA	BRAUN NiMH 2700
	QV-5700	AA	BRAUN NiMH 2700
	QV-7000SX	AA	BRAUN NiMH 2700
	QV-8000SX	AA	BRAUN NiMH 2700
	QV-R40	AA	BRAUN NiMH 2700
	QV-R41	AA	BRAUN NiMH 2700
	QV-R51	AA	BRAUN NiMH 2700
	QV-R52	AA	BRAUN NiMH 2700
	QV-R61	AA	BRAUN NiMH 2700
	QV-R62	AA	BRAUN NiMH 2700

Fuji					
	Digital Q1	AA	BRAUN NiMH 2700		
	DS 7	AA	BRAUN NiMH 2700		
	DX 5	AA	BRAUN NiMH 2700		
	DX 7	AA	BRAUN NiMH 2700		
	DX 8	AA	BRAUN NiMH 2700		
	DX 9	3,7V/2000mAh	BDP-FNP100	B122	59332
	DX 10	AA	BRAUN NiMH 2700		
	EX 20	AA	BRAUN NiMH 2700		
	FinePix 30i	AA	BRAUN NiMH 2700		
	FinePix 40i	AA	BRAUN NiMH 2700		
	FinePix 1300	AA	BRAUN NiMH 2700		
	FinePix 1400 Zoom	AA	BRAUN NiMH 2700		
	FinePix 2300	AA	BRAUN NiMH 2700		
	FinePix 2400 Zoom	AA	BRAUN NiMH 2700		
	FinePix 2600 Zoom	AA	BRAUN NiMH 2700		
	FinePix 2800 Zoom	AA	BRAUN NiMH 2700		
	FinePix 4700 Zoom	AA	BRAUN NiMH 2700		
	FinePix 4800 Zoom	3,7V/1400mAh	BDP-FNP80	B121	59331

<b>Fuji</b>	FinePix 4900 Zoom	3,7V/1400mAh	BDP-FNP80	B121	59331
	FinePix 6800 Zoom	3,7V/1400mAh	BDP-FNP80	B121	59331
	FinePix 6900 Zoom	3,7V/1400mAh	BDP-FNP80	B121	59331
	FinePix A101	AA	BRAUN NiMH 2700		
	FinePix A120	AA	BRAUN NiMH 2700		
	FinePix A201	AA	BRAUN NiMH 2700		
	FinePix A202	AA	BRAUN NiMH 2700		
	FinePix A203	AA	BRAUN NiMH 2700		
	FinePix A204	AA	BRAUN NiMH 2700		
	FinePix A205S	AA	BRAUN NiMH 2700		
	FinePix A210	AA	BRAUN NiMH 2700		
	FinePix A303	AA	BRAUN NiMH 2700		
	FinePix A310	AA	BRAUN NiMH 2700		
	FinePix A330	AA	BRAUN NiMH 2700		
	FinePix A340	AA	BRAUN NiMH 2700		
	FinePix A345	AA	BRAUN NiMH 2700		
	FinePix A350	AA	BRAUN NiMH 2700		
	BIGJOB HD-3W	AA	BRAUN NiMH 2700		
	FinePix A400	AA	BRAUN NiMH 2700		
	FinePix A500	AA	BRAUN NiMH 2700		
	FinePix A510	AA	BRAUN NiMH 2700		
	FinePix A600	AA	BRAUN NiMH 2700		
	FinePix A610	AA	BRAUN NiMH 2700		
	FinePix A700	AA	BRAUN NiMH 2700		
	FinePix A800	AA	BRAUN NiMH 2700		
	FinePix A820	AA	BRAUN NiMH 2700		
	FinePix A825	AA	BRAUN NiMH 2701		
	FinePix A850	AA	BRAUN NiMH 2700		
	FinePix A900	AA	BRAUN NiMH 2700		
	FinePix A 920	AA	BRAUN NiMH 2701		
	FinePix E500	AA	BRAUN NiMH 2701		
	FinePix E510	AA	BRAUN NiMH 2701		
	FinePix E550	AA	BRAUN NiMH 2701		
	FinePix E900	AA	BRAUN NiMH 2701		
	FinePix F10	3,7V/1800mAh	BDP-FNP120	B123	59333
	FinePix F11	3,7V/1800mAh	BDP-FNP120	B123	59333
	FinePix F20	3,7V/1150mAh	BDP-FNP70	B15	59213
	FinePix F30	3,7V/1800mAh	BDP-FNP95	B16	59214
	FinePix F31fd	3,7V/1800mAh	BDP-FNP95	B16	59214
	FinePix F40fd	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F45fd	3,7V/1150mAh	BDP-FNP70	B15	59213
	FinePix F47fd	3,7V/1150mAh	BDP-FNP70	B15	59213
	FinePix F50fd	3,7V/1000mAh	BDP-FNP50	B94	59304
	FinePix F60fd	3,7V/1000mAh	BDP-FNP50	B94	59304
	FinePix F100fd	3,7V/1000mAh	BDP-FNP50	B94	59304
	<b>FinePix F-70 EXR</b>	<b>3,7V/1000mAh</b>	<b>BDP-FNP50</b>	<b>B94</b>	<b>59304</b>
	FinePix F170 EXR	3,7V/1000mAh	BDP-FNP50	B94	59304
	FinePix F200EXR	3,7V/1000mAh	BDP-FNP50	B94	59304
	FinePix F401 Zoom	3,7V/1100mAh	BDP-FNP60	B12	59211

<b>Fuji</b>	FinePix F402	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F410	3,7V/1100mAh	BDP-FNP60	B12	59211
	FinePix F455	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F460	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F470	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F480	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F601Zoom	3,7V/1100mAh	BDP-FNP60	B12	59211
	FinePix F603	3,7V/1100mAh	BDP-FNP60	B12	59211
	FinePix F610	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F650	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F700	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F710	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix F810	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix J10	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix J20	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix J25	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix J27	3,7V/660mAh	BDP-FNP45	B95	59305
	Fine Pix J30	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix J50	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix J100	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix J110w	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix J120	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix J150W	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix J210	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix J250	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix M603	3,7V/1100mAh	BDP-FNP60	B12	59211
	FinePix M603Zoom	3,7V/1800mAh	BDP-FNP120	B123	59333
	FinePix S1 Pro	AA	BRAUN NiMH 2700		
	FinePix S2 Pro	AA	BRAUN NiMH 2700		
	FinePix S3 Pro	AA	BRAUN NiMH 2700		
	FinePix S5 Pro	7,4V/1500mAh	BDO-FNP150	B125	59335
	FinePix S20 Pro	AA	BRAUN NiMH 2700		
	FinePix S100FS	7,4V/1150mAh	BDP-FNP140	B124	59334
	FinePix S200EXR	7,4V/1150mAh	BDP-FNP140	B124	59334
	FinePix S304	AA	BRAUN NiMH 2700		
	FinePix S602Zoom	AA	BRAUN NiMH 2700		
	FinePix S1000fd	AA	BRAUN NiMH 2700		
	FinePix S 1500	AA	BRAUN NiMH 2700		
	FinePix S 2000HD	AA	BRAUN NiMH 2700		
	FinePix S2000HP	AA	BRAUN NiMH 2700		
	FinePix S3000	AA	BRAUN NiMH 2700		
	FinePix S3500	AA	BRAUN NiMH 2700		
	FinePix S5000	AA	BRAUN NiMH 2700		
	FinePix S5500	AA	BRAUN NiMH 2700		
	FinePix S5600	AA	BRAUN NiMH 2700		
	FinePix S5700	AA	BRAUN NiMH 2700		
	Finepix S5800	AA	BRAUN NiMH 2700		
	FinePix S6500fd	AA	BRAUN NiMH 2700		
	FinePix S7000	AA	BRAUN NiMH 2700		
	FinePix S8000fd	AA	BRAUN NiMH 2700		

<b>Fuji</b>	FinePix S8100fd	AA	BRAUN NiMH 2700		
	FinePix S9500	AA	BRAUN NiMH 2700		
	FinePix S9600	AA	BRAUN NiMH 2700		
	FinePix V10	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix Z1	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix Z2	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix Z3	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix Z5fd	3,7V/750mAh	BDP-FNP40	B10	59209
	FinePix Z10fd	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix Z20fd	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix Z30	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix Z33WP	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix Z35	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix Z37	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix Z100fd	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix Z200fd	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix Z300	3,7V/660mAh	BDP-FNP45	B95	59305
	FinePix Real 3DW1	3,7V/1800mAh	BDP-FNP95	B16	59214
	MX-600 Zoom	3,7V/2000mAh	BDP-FNP100	B122	59332
	MX-700	3,7V/2000mAh	BDP-FNP100	B122	59332
	MX-1200	AA	BRAUN NiMH 2700		
	MX-1500	AA	BRAUN NiMH 2700		
	MX-1700Zoom	3,7V/1400mAh	BDP-FNP80	B121	59331
	MX-2700	3,7V/1400mAh	BDP-FNP80	B121	59331
	MX-2900Zoom	3,7V/1400mAh	BDP-FNP80	B121	59331
	MX-4900Zoom	3,7V/1400mAh	BDP-FNP80	B121	59331
	MX-5000	AA	BRAUN NiMH 2700		
	MX-6800	3,7V/1400mAh	BDP-FNP80	B121	59331
	MX-6900	3,7V/1400mAh	BDP-FNP80	B121	59331
<b>HP</b>	M447	AA	BRAUN NiMH 2700		
	M525	AA	BRAUN NiMH 2700		
	M527	AA	BRAUN NiMH 2700		
	M537	AA	BRAUN NiMH 2700		
	M547	AA	BRAUN NiMH 2700		
	M627	AA	BRAUN NiMH 2700		
	M637	AA	BRAUN NiMH 2700		
	M737	AA	BRAUN NiMH 2700		
	Mz67	AA	BRAUN NiMH 2700		
	R507	3,7V/1100mAh	BDP-FNP60	B12	59211
	R707	3,7V/1100mAh	BDP-FNP60	B12	59211
	R717	3,7V/1100mAh	BDP-FNP60	B12	59211
	R718	3,7V/1100mAh	BDP-FNP60	B12	59211
	R 727	3,7V/1100mAh	BDP-FNP60	B12	59211
	R742	3,7V/1100mAh	BDP-FNP60	B12	59211
	R827	3,7V/1100mAh	BDP-FNP60	B12	59211
	R837	3,7V/1100mAh	BDP-FNP60	B12	59211
	R847	3,7V/1100mAh	BDP-FNP60	B12	59211
	R927	3,7V/1100mAh	BDP-FNP60	B12	59211



<b>HP</b>	R937	3,7V/1100mAh	BDP-FNP60	B12	59211
	R967	3,7V/1100mAh	BDP-FNP60	B12	59211
<b>Hyundai</b>					
	A 5324	AA	BRAUN NiMH 2700		
	A 5324i	AA	BRAUN NiMH 2700		
	A 8324	AA	BRAUN NiMH 2700		
	A 9325	AA	BRAUN NiMH 2700		
	L 7330	3,7V/750mAh	BDP-FNP40	B10	59209
	S 800	3,7V/750mAh	BDP-FNP40	B10	59209
<b>Kodak</b>					
	C140	AA	BRAUN NiMH 2700		
	C142	AA	BRAUN NiMH 2700		
	C180	AA	BRAUN NiMH 2700		
	C182	AA	BRAUN NiMH 2700		
	C190	AA	BRAUN NiMH 2700		
	C310	AA	BRAUN NiMH 2700		
	C330	AA	BRAUN NiMH 2700		
	C433	AA	BRAUN NiMH 2700		
	C503	AA	BRAUN NiMH 2700		
	C530	AA	BRAUN NiMH 2700		
	C533	AA/CR-V3	BRAUN NiMH 2700		
	C603	AA	BRAUN NiMH 2700		
	C613	AA	BRAUN NiMH 2700		
	C643	AA/CR-V3	BRAUN NiMH 2700		
	C653	AA	BRAUN NiMH 2700		
	C663	AA/CR-V3	BRAUN NiMH 2700		
	C713	AA	BRAUN NiMH 2700		
	C743	AA	BRAUN NiMH 2700		
	C813	AA	BRAUN NiMH 2700		
	C875	AA/CR-V3	BRAUN NiMH 2700		
	C913	AA	BRAUN NiMH 2700		
	C1013	AA	BRAUN NiMH 2700		
	DC4800	3,7V/1400mAh	BDP-FNP80	B121	59331
	DC4800Zoom	3,7V/1400mAh	BDP-FNP80	B121	59331
	DX 6490	3,7V/1700mAh	BDP-DBL50	B137	59345
	DX 7440	3,7V/1700mAh	BDP-DBL50	B137	59345
	DX 7440 Zoom	3,7V/1700mAh	BDP-DBL50	B137	59345
	DX 7590	3,7V/1700mAh	BDP-DBL50	B137	59345
	DX 7590 Zoom	3,7V/1700mAh	BDP-DBL50	B137	59345
	DX 7630	3,7V/1700mAh	BDP-DBL50	B137	59345
	M320	3,7V/720mAh	BDP-KLIC7001	B25	59223
	M340	3,7V/720mAh	BDP-KLIC7001	B25	59223
	M341	3,7V/720mAh	BDP-KLIC7001	B25	59223
	M380	3,7V/1050mAh	BDP-KLIC7003	B27	59225
	M381	3,7V/1050mAh	BDP-KLIC7003	B27	59225
	M420	3,7V/1050mAh	BDP-KLIC7003	B27	59225
	M530	3,7V/660mAh	BDP-KLIC7006	B96	59306
	M550	3,7V/660mAh	BDP-KLIC7006	B96	59306
	M575	3,7V/660mAh	BDP-KLIC7006	B96	59306
	M580	3,7V/660mAh	BDP-KLIC7006	B96	59306
	M753	3,7V/720mAh	BDP-KLIC7001	B25	59223

<b>Kodak</b>	M763	3,7V/720mAh	BDP-KLIC7001	B25	59223
	M853	3,7V/720mAh	BDP-KLIC7001	B25	59223
	M863	3,7V/720mAh	BDP-KLIC7001	B25	59223
	M873	3,7V/660mAh	BDP-KLIC7006	B96	59306
	M873 Zoom	3,7V/660mAh	BDP-KLIC7006	B96	59306
	M883	3,7V/660mAh	BDP-KLIC7006	B96	59306
	M883 Zoom	3,7V/660mAh	BDP-KLIC7006	B96	59306
	M893IS	3,7V/720mAh	BDP-KLIC7001	B25	59223
	M1033	3,7V/1000mAh	BDP-KLIC7004	B97	59307
	M1063	3,7V/720mAh	BDP-KLIC7001	B25	59223
	M1073IS	3,7V/720mAh	BDP-KLIC7001	B25	59223
	M1093IS	3,7V/1000mAh	BDP-KLIC7004	B97	59307
	P712	3,7V/1800mAh	BDP-KLIC5001	B24	59222
	P850	3,7V/1700mAh	BDP-DBL50	B137	59345
	P880	3,7V/1800mAh	BDP-KLIC5001	B24	59222
	V570	3,7V/720mAh	BDP-KLIC7001	B25	59223
	V603	3,7V/600mAh	BDP-KLIC7002	B26	59224
	V610	3,7V/720mAh	BDP-KLIC7001	B25	59223
	V705	3,7V/720mAh	BDP-KLIC7001	B25	59223
	V803	3,7V/1050mAh	BDP-KLIC7003	B27	59225
	V1003	3,7V/1050mAh	BDP-KLIC7003	B27	59225
	V1073	3,7V/1000mAh	BDP-KLIC7004	B97	59307
	V1233	3,7V/1050mAh	BDP-KLIC7003	B27	59225
	V1253	3,7V/1000mAh	BDP-KLIC7004	B97	59307
	V1273	3,7V/1000mAh	BDP-KLIC7004	B97	59307
	Z612	3,7V/1520mAh	BDP-KLIC8000	B29	59227
	Z650	AA/CR-V3	BRAUN NiMH 2700		
	Z710	AA/CR-V3	BRAUN NiMH 2700		
	Z712 IS	AA/CR-V3	BRAUN NiMH 2700		
	Z 730	3,7V/1700mAh	BDP-DBL50	B137	59345
	Z 730 Zoom	3,7V/1700mAh	BDP-DBL50	B137	59345
	Z 750	3,7V/1100mAh	BDP-FNP60	B12	59211
	Z 760	3,7V/1700mAh	BDP-DBL50	B137	59345
	Z 760 Zoom	3,7V/1700mAh	BDP-DBL50	B137	59345
	Z812IS	AA/CR-V3	BRAUN NiMH 2700		
	Z885	AA/CR-V3	BRAUN NiMH 2700		
	Z915	AA	BRAUN NiMH 2700		
	Z950	3,7V/1050mAh	BDP-KLIC7003	B27	59225
	Z950IS	3,7V/1050mAh	BDP-KLIC7003	B27	59225
	SLICE	3,7V/730mAh	BPD-KLIC7000	B25	59223
	Z980	AA	BRAUN NiMH 2700		
	Z1012IS	3,7V/1520mAh	BDP-KLIC8000	B29	59227
	Z1015IS	3,7V/1520mAh	BDP-KLIC8000	B29	59227
	Z1085IS	3,7V/1520mAh	BDP-KLIC8000	B29	59227
	Z1275	AA	BRAUN NiMH 2700		
	Z1285	AA	BRAUN NiMH 2700		
	Z1485IS	3,7V/1520mAh	BDP-KLIC8000	B29	59227

<b>Kodak</b>	Z 7590	3,7V/1700mAh	BDP-DBL50	B137	59345
	Z 7590 Zoom	3,7V/1700mAh	BDP-DBL50	B137	59345
	Z D710	AA	BRAUN NiMH 2700		
	Z8612IS	3,7V/1520mAh	BDP-KLIC8000	B29	59227
	Easy Share One	3,7V/1100mAh	BDP-FNP60	B12	59211
	LS 420	3,7V/1100mAh	BDP-FNP60	B12	59211
	LS 443	3,7V/1100mAh	BDP-FNP60	B12	59211
	LS 633	3,7V/1100mAh	BDP-FNP60	B12	59211
	LS 742	3,7V/1100mAh	BDP-FNP60	B12	59211
	LS753	3,7V/1100mAh	BDP-FNP60	B12	59211

<b>Konica/ Minolta</b>	DG-X50-K	3,7V/660mAh	BDP-PELI72	B120	59330
	DG-X50R	3,7V/660mAh	BDP-PELI72	B120	59330
	DG-X50S	3,7V/660mAh	BDP-PELI72	B120	59330
	Dimage X50	3,7V/660mAh	BDP-PELI72	B120	59330
	Dimage X60	3,7V/660mAh	BDP-PELI72	B120	59330
	Dimage Xg	3,7V/750mAh	BDP-MNP200	B90	59299
	Dimage X	3,7V/750mAh	BDP-MNP200	B90	59299
	Dimage Xi	3,7V/750mAh	BDP-MNP200	B90	59299
	Dimage Xt	3,7V/750mAh	BDP-MNP200	B90	59299
	Dimage XtBiz	3,7V/750mAh	BDP-MNP200	B90	59299

<b>Leica</b>	C-Lux 2	3,7V/1150mAh	BDP-BPDC4	B35	59233
	D-Lux 3	3,7V/1150mAh	BDP-BPDC4	B35	59233
	D-Lux 4	3,7V/1150mAh	BDP-BPDC4	B35	59233
	V-Lux 1	7,4V/750mAh	BDP-S006	B45	59243
	M8	3,7V/1900mAh	BDP-BM8	B34	59232
	M9	3,7V/1900mAh	BDP-BM8	B34	59232
	Digilux Zoom	3,7V/1400mAh	BDP-FNP80	B121	59331

<b>Maginon</b>	DC 6600	3,7V/720mAh	BDP-MNP900	B104	59314
	DC 6800	3,7V/720mAh	BDP-MNP900	B104	59314
	DC 6900	AA	BRAUN NiMH 2700		
	DC 7800	AA	BRAUN NiMH 2700		
	DC 8000	AA	BRAUN NiMH 2700		
	DSC 55	AA	BRAUN NiMH 2700		
	DSC 5060	AA	BRAUN NiMH 2700		
	Marlin	AA	BRAUN NiMH 2700		
	Slimline X4	3,7V/720mAh	BDP-MNP900	B104	59314
	Slimline X5	3,7V/720mAh	BDP-MNP900	B104	59314
	Slimline X6	3,7V/720mAh	BDP-MNP900	B104	59314
	Slimline X50	3,7V/720mAh	BDP-MNP900	B104	59314
	Slimline X60	3,7V/720mAh	BDP-MNP900	B104	59314
	Slimline XS6	3,7V/720mAh	BDP-MNP900	B104	59314
	Superslim XS 7	3,7V/1100mAh	BDP-NP60	B12	59211
	Superslim XS 80	3,7V/1100mAh	BDP-NP60	B12	59211

<b>Medion</b>	MD 85544	AA	BRAUN NiMH 2700		
	MD 85680	AA	BRAUN NiMH 2700		
	MD 85733	3,7V/1100mAh	BDP-FNP60	B12	59211
	MD 85806	3,7V/1100mAh	BDP-FNP60	B12	59211
	MD 85820	3,7V/720mAh	BDP-MNP900	B104	59314
	MD 85830	AA	BRAUN NiMH 2700		
	MD 85833	AA	BRAUN NiMH 2700		

<b>Nikon</b>	Coolpix 775	7,4V/800mAh	BDP-ENEL1	B17	59215
	Coolpix 880	7,4V/800mAh	BDP-ENEL1	B17	59215
	Coolpix 885	7,4V/800mAh	BDP-ENEL1	B17	59215
	Coolpix 995	7,4V/800mAh	BDP-ENEL1	B17	59215
	Coolpix 3700	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix 4200	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix 4500	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix 4800	7,4V/800mAh	BDP-ENEL1	B17	59215
	Coolpix 5000	7,4V/800mAh	BDP-ENEL1	B17	59215
	Coolpix 5400	7,4V/800mAh	BDP-ENEL1	B17	59215
	Coolpix 5700	7,4V/800mAh	BDP-ENEL1	B17	59215
	Coolpix 5900	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix 7900	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix 8700	7,4V/800mAh	BDP-ENEL1	B17	59215
	D2Xs	11,1V/2600mAh	BDP-ENEL4A	B20	59218
	D2Hs	11,1V/2600mAh	BDP-ENEL4A	B20	59218
	D3	11,1V/2600mAh	BDP-ENEL4A	B20	59218
	D3s	11,1V/2600mAh	BDP-ENEL4A	B20	59218
	D3x	11,1V/2600mAh	BDP-ENEL4A	B20	59218
	D200	7,4V/1620mAh	BDP-ENEL3E	B19	59217
	D300	7,4V/1620mAh	BDP-ENEL3E	B19	59217
	<b>D300s</b>	<b>7,4V/1620mAh</b>	<b>BDP-ENEL3E</b>	<b>B19</b>	<b>59217</b>
	D700	7,4V/1620mAh	BDP-ENEL3E	B19	59217
	D40	7,4V/1100mAh	BDP-ENEL9	B23	59221
	D40x	7,4V/1100mAh	BDP-ENEL9	B23	59221
	D50	7,4V/1620mAh	BDP-ENEL3	B18	59216
	D60	7,4V/1100mAh	BDP-ENEL9	B23	59221
	D70, D70s	7,4V/1620mAh	BDP-ENEL3	B18	59216
	D80	7,4V/1620mAh	BDP-ENEL3	B18	59216
	D 90	7,4V/1620mAh	BDP-ENEL3E	B19	59217
	D100	7,4V/1620mAh	BDP-ENEL3	B18	59216
	D 300S	7,4V/1620mAh	BDP-ENEL3E	B19	59217
	<b>D 3000</b>	<b>7,4V/1290mAh</b>	<b>BDP-ENEL9a</b>	<b>B165</b>	<b>59373</b>
	D 5000	7,4V/1290mAh	BDP-ENEL9a	B165	59373
	Coolpix L2	AA	BRAUN NiMH 2700		
	Coolpix L3	AA	BRAUN NiMH 2700		
Coolpix L4	AA	BRAUN NiMH 2700			
Coolpix L5	AA	BRAUN NiMH 2700			
Coolpix L6	AA	BRAUN NiMH 2700			
Coolpix L10	AA	BRAUN NiMH 2700			

<b>Nikon</b>	Coolpix L14	AA	BRAUN NiMH 2700		
	Coolpix L15	AA	BRAUN NiMH 2700		
	Coolpix L16	AA	BRAUN NiMH 2700		
	Coolpix L18	AA	BRAUN NiMH 2700		
	Coolpix L19	AA	BRAUN NiMH 2700		
	Coolpix L20	AA	BRAUN NiMH 2700		
	Coolpix L100	AA	BRAUN NiMH 2700		
	Coolpix P3	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix P4	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix P5	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix P50	AA	BRAUN NiMH 2700		
	Coolpix P60	AA	BRAUN NiMH 2700		
	Coolpix P80	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix P90	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix P5000	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix P5100	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix P6000	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix S5	3,7V/730mAh	BDP-ENEL8	B22	59220
	Coolpix S7c	3,7V/730mAh	BDP-ENEL8	B22	59220
	Coolpix S9	3,7V/730mAh	BDP-ENEL8	B22	59220
	Coolpix S10	3,7V/1100mAh	BDP-ENEL5	B21	59219
	Coolpix S50c	3,7V/730mAh	BDP-ENEL8	B22	59220
	Coolpix S51	3,7V/730mAh	BDP-ENEL8	B22	59220
	Coolpix S51c	3,7V/730mAh	BDP-ENEL8	B22	59220
	Coolpix S52	3,7V/730mAh	BDP-ENEL8	B22	59220
	Coolpix S52c	3,7V/730mAh	BDP-ENEL8	B22	59220
	Coolpix S60	3,7V/740mAh	BDP-ENEL10	B48	59246
	<b>Coolpix S70</b>	<b>3,7V/1050mAh</b>	<b>BDP-ENEL12</b>	<b>B145</b>	<b>59353</b>
	Coolpix S200	3,7V/740mAh	BDP-ENEL10	B48	59246
	Coolpix S210	3,7V/740mAh	BDP-ENEL10	B48	59246
	Coolpix S220	3,7V/740mAh	BDP-ENEL10	B48	59246
	Coolpix S230	3,7V/740mAh	BDP-ENEL10	B48	59246
	Coolpix S500 silver	3,7V/740mAh	BDP-ENEL10	B48	59246
	Coolpix S500 schwarz	3,7V/740mAh	BDP-ENEL10	B48	59246
	Coolpix S510	3,7V/740mAh	BDP-ENEL10	B48	59246
	Coolpix S520	3,7V/740mAh	BDP-ENEL10	B48	59246
	Coolpix S550	3,7V/680mAh	BDP-PELI78	B119	59329
	Coolpix S560	3,7V/680mAh	BDP-PELI78	B119	59329
	<b>Coolpix S570</b>	<b>3,7V/740mAh</b>	<b>BDP-ENEL10</b>	<b>B48</b>	<b>59246</b>
	Coolpix S600	3,7V/740mAh	BDP-ENEL10	B48	59246
	Coolpix S610	3,7V/1050mAh	BDP-ENEL12	B145	59353
	Coolpix S610c	3,7V/1050mAh	BDP-ENEL12	B145	59353
	<b>Coolpix S620</b>	<b>3,7V/1050mAh</b>	<b>BDP-ENEL12</b>	<b>B145</b>	<b>59353</b>
	Coolpix S630	3,7V/1050mAh	BDP-ENEL12	B145	59353
	<b>Coolpix S640</b>	<b>3,7V/1050mAh</b>	<b>BDP-ENEL12</b>	<b>B145</b>	<b>59353</b>
Coolpix S650	3,7V/1050mAh	BDP-ENEL12	B145	59353	
Coolpix S700	3,7V/740mAh	BDP-ENEL10	B48	59246	
Coolpix S710	3,7V/1050mAh	BDP-ENEL12	B145	59353	
<b>Coolpix S1000pj</b>	<b>3,7V/1050mAh</b>	<b>BDP-ENEL12</b>	<b>B145</b>	<b>59353</b>	

<b>Olympus</b>	C50Zoom	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	C60Zoom	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	C70 ZOOM	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	C760, C765, C770	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	C-5000 ZOOM	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	C-5060	7,4V/1620mAh	BDP-BLM1	B37	59235
	C-7070	7,4V/1620mAh	BDP-BLM1	B37	59235
	C-8080	7,4V/1620mAh	BDP-BLM1	B37	59235
	E-1	7,4V/1620mAh	BDP-BLM1	B37	59235
	E-3	7,4V/1620mAh	BDP-BLM1	B37	59235
	E-30	7,4V/1620mAh	BDP-BLM1	B37	59235
	E-300	7,4V/1620mAh	BDP-BLM1	B37	59235
	E-330	7,4V/1620mAh	BDP-BLM1	B37	59235
	E-400	7,4V/1150mAh	BDP-BLS1	B38	59236
	E-410	7,4V/1150mAh	BDP-BLS1	B38	59236
	E-420	7,4V/1150mAh	BDP-BLS1	B38	59236
	E-450	7,4V/1150mAh	BDP-BLS1	B38	59236
	E-500	7,4V/1620mAh	BDP-BLM1	B37	59235
	E-510	7,4V/1620mAh	BDP-BLM1	B37	59235
	E-520	7,4V/1620mAh	BDP-BLM1	B37	59235
	<b>E-600</b>	<b>7,4V/1150mAh</b>	<b>BDP-BLS1</b>	<b>B38</b>	<b>59236</b>
	E-620	7,4V/1150mAh	BDP-BLS1	B38	59236
	E-P1	7,4V/1150mAh	BDP-BLS1	B38	59236
	FE-20	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-26	AA	BRAUN NiMH 2700		
	FE-45	AA	BRAUN NiMH 2700		
	FE-46	AA	BRAUN NiMH 2700		
	FE-130	AA	BRAUN NiMH 2700		
	FE-140	AA	BRAUN NiMH 2700		
	FE150	3,7V/740mAh	BDP-LI40B	B32	59230
	FE160	3,7V/740mAh	BDP-LI40B	B32	59230
	FE-170	AA	BRAUN NiMH 2700		
	FE-180	AA	BRAUN NiMH 2700		
	FE-190	3,7V/740mAh	BDP-LI40B	B32	59230
	FE-200	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	FE-210	AA	BRAUN NiMH 2700		
	FE-230	3,7V/740mAh	BDP-LI40B	B32	59230
	FE-240	3,7V/740mAh	BDP-LI40B	B32	59230
	FE-250	3,7V/740mAh	BDP-LI40B	B32	59230
	FE-270	AA	BRAUN NiMH 2700		
	FE-280	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-290	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-300	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-310	AA	BRAUN NiMH 2700		
	FE-340	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-350	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-360	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-370	3,7V/680mAh	BDP-OLI-60B	B146	59354
	FE-3010	3,7V/740mAh	BDP-LI42B	B32	59230

<b>Olympus</b>	FE-4000	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-4010	3,7V/740mAh	BDP-LI42B	B32	59230
	FE -4030	3,7V/740mAh	BDP-LI42B	B32	59230
	FE -4040		BDP-70B		
	FE-5000	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-5020	3,7V/740mAh	BDP-LI42B	B32	59230
	FE-5030	3,7V/740mAh	BDP-LI42B	B32	59230
	IR300	3,7V/740mAh	BDP-LI40B	B32	59230
	IR500	3,7V/740mAh	BDP-LI40B	B32	59230
	mju 300	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	mju 400, mju 410	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	mju 500	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	mju 550WP	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 890WP	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 600	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	mju 700	3,7V/740mAh	BDP-LI40B	B32	59230
	mju 720SW	3,7V/740mAh	BDP-LI40B	B32	59230
	mju 725SW	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 730	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 740	3,7V/740mAh	BDP-LI40B	B32	59230
	mju 750	3,7V/740mAh	BDP-LI40B	B32	59230
	mju 760	3,7V/740mAh	BDP-LI40B	B32	59230
	mju 770 SW	3,7V/740mAh	BDP-LI40B	B32	59230
	mju 780	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 790 SW	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 800	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	mju 810	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	mju 820	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 830	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 840	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 850SW	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 1000	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	mju 1010	3,7V/925mAh	BDP-OLI50B	B102	59312
	mju 1020	3,7V/925mAh	BDP-OLI50B	B102	59312
	mju 1030SW	3,7V/925mAh	BDP-OLI50B	B102	59312
	mju 1040	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 1050SW	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 1060	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 1200	3,7V/740mAh	BDP-LI42B	B32	59230
	mju Tough 3000	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 5000	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 5010	3,7V/925mAh	BDP-OLI50B	B102	59312
	<b>mju 6020</b>	<b>3,7V/925mAh</b>	<b>BDP-OLI50B</b>	<b>B102</b>	<b>59312</b>
	mju 7000	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 7010 Titanium	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 7020 Titanium	3,7V/740mAh	BDP-LI42B	B32	59230
	mju 7040 Copper Blue	3,7V/740mAh	BDP-LI42B	B32	59230
	<b>mju Tough 8020</b>	<b>3,7V/925mAh</b>	<b>BDP-OLI50B</b>	<b>B102</b>	<b>59312</b>
	mju 9000	3,7V/925mAh	BDP-OLI50B	B102	59312

<b>Olympus</b>	mju 9010	3,7V/925mAh	BDP-OLI50B	B102	59312
	mju TOUGH 1030SW	3,7V/925mAh	BDP-OLI50B	B102	59312
	mju TOUGH 6000	3,7V/925mAh	BDP-OLI50B	B102	59312
	mju TOUGH 6010 Tit.	3,7V/925mAh	BDP-OLI50B	B102	59312
	mju TOUGH 8000	3,7V/925mAh	BDP-OLI50B	B102	59312
	<b>Pen EP1</b>		<b>BLS-1</b>		
	<b>Pen EP2</b>		<b>BLS-1</b>		
	SP-350	AA	BRAUN NiMH 2700		
	SP-510 UZ	AA	BRAUN NiMH 2700		
	SP-550 UZ	AA	BRAUN NiMH 2700		
	SP-560 UZ	AA	BRAUN NiMH 2700		
	SP-565 UZ	AA	BRAUN NiMH 2700		
	SP-570 UZ	AA	BRAUN NiMH 2700		
	SP-590UZ	AA	BRAUN NiMH 2700		
	SP-700	3,7V/740mAh	BDP-LI40B	B32	59230
	<b>SP-800UZ</b>	<b>3,7V/925mAh</b>	<b>BDP-OLI50B</b>	<b>B102</b>	<b>59312</b>
	STYLUS 1010	3,7V/925mAh	BDP-OLI50B	B102	59312
	STYLUS 1020	3,7V/925mAh	BDP-OLI50B	B102	59312
	STYLUS 1030SW	3,7V/925mAh	BDP-OLI50B	B102	59312
	X825	3,7V/740mAh	BDP-LI42B	B32	59230
x560 WP cooper organge	3,7V/740mAh	BDP-LI42B	B32	59230	

<b>Panasonic</b>	DMC-FP8	3,6V/940mAh	BDP-PBCF10E	B161	59369
	DMC-FS3	3,7V/1000mAh	BDP-BCE10	B33	59231
	DMC-FS5	3,7V/1000mAh	BDP-BCE10	B33	59231
	DMC-FS6	3,6V/940mAh	BDP-PBCF10E	B161	59369
	DMC-FS7	3,6V/940mAh	BDP-PBCF10E	B161	59369
	<b>DMC-FS10</b>	<b>3,6V/940mAh</b>	<b>BDP-PBCF10E</b>	<b>B161</b>	<b>59369</b>
	<b>DMC-FS11</b>	<b>3,6V/940mAh</b>	<b>BDP-PBCF10E</b>	<b>B161</b>	<b>59369</b>
	DMC-FS15	3,6V/940mAh	BDP-PBCF10E	B161	59369
	DMC-FS20	3,7V/1000mAh	BDP-BCE10	B33	59231
	DMC-FS25	3,6V/940mAh	BDP-PBCF10E	B161	59369
	<b>DMC-FS30 / FS 35</b>	<b>3,6V/940mAh</b>	<b>BDP-PBCF10E</b>	<b>B161</b>	<b>59369</b>
	DMC-FS33		Not Available		
	DMC-FS62	3,6V/940mAh	BDP-PBCF10E	B161	59369
	DMC-FT1	3,6V/940mAh	BDP-PBCF10E	B161	59369
	DMC-FX01	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-FX2	3,7V/750mAh	CGA-S004		
	DMC-FX03	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-GF1	7,2V/1250 mAh	BDP-PBLB13	B159	59367
	DMC-GF1K	7,2V/1250 mAh	Not Available		
	DMC-GF1C	7,2V/1250 mAh	Not Available		
	<b>DMC-FP1</b>		<b>Not Available</b>		
	DMC-FP8	3,6V/1000mAh	Not Available		
	DMC-FX07	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-FX7	3,7V/750mAh	CGS-S004		
	DMC-FX8	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-FX9	3,7V/1150mAh	BDP-S005E	B39	59237

<b>Panasonic</b>	DMC-FX10	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-FX12	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-FX30	3,7V/1000mAh	BDP-BCE10	B33	59231
	DMC-FX33	3,7V/1000mAh	BDP-BCE10	B33	59231
	DMC-FX35	3,7V/1000mAh	BDP-BCE10	B33	59231
	DMC-FX37	3,7V/1000mAh	BDP-BCE10	B33	59231
	DMC-FX40	3,6V/940mAh	BDP-PBCF10E	B161	59369
	DMC-FX50	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-FX55	3,7V/1000mAh	BDP-BCE10	B33	59231
	<b>DMC-FX60</b>	<b>3,6V/940mAh</b>	<b>BDP-PBCF10E</b>	<b>B161</b>	<b>59369</b>
	<b>DMC-FX66</b>		<b>Not Available</b>		
	DMC-FX100	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-FX150	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-FX500	3,7V/1000mAh	BDP-BCE10	B33	59231
	DMC-FX550	3,6V/940mAh	BDP-PBCF10E	B161	59369
	DMC-FZ7	7,2V/750mAh	BDP-S006	B45	59243
	DMC-FZ8	7,4V/750mAh	BDP-S006	B45	59243
	DMC-FZ18	7,4V/750mAh	BDP-S006	B45	59243
	DMC-FZ28	7,4V/750mAh	BDP-S006	B45	59243
	DMC-FZ30	7,4V/750mAh	BDP-S006	B45	59243
	<b>DMC-FZ38</b>		<b>Not Available</b>		
	DMC-FZ50	7,4V/750mAh	BDP-S006	B45	59243
	DMC-G 1	7,2V/1250mAh	BDP-PBLB13	B159	59367
	<b>DMC-G2</b>	<b>7,2V/1250mAh</b>	<b>BDP-PBLB13</b>	<b>B159</b>	<b>59367</b>
	<b>DMC-G10</b>	<b>7,2V/1250mAh</b>	<b>BDP-PBLB13</b>	<b>B159</b>	<b>59367</b>
	DMC-GH 1K	7,2V/1250mAh	BDP-PBLB13	B159	59367
	DMC-G 1K	7,2V/1250mAh	BDP-PBLB13	B159	59367
	<b>DMC-GF 1</b>	<b>7,2V/1250mAh</b>	<b>BDP-PBLB13</b>	<b>B159</b>	<b>59367</b>
	DMC G 1W	7,2V/1250mAh	BDP-PBLB13	B159	59367
	DMC-L1	7,2V/1500mAh	CGR-S603		
	DMC-L10	7,2V/1320mAh	BLA-13		
	DMC-LS3	AA	BRAUN NiMH 2700		
	DMC-LS60	AA	BRAUN NiMH 2700		
	DMC-LS65	AA	BRAUN NiMH 2700		
	DMC-LS75	AA	BRAUN NiMH 2700		
	DMC-LS80	AA	BRAUN NiMH 2700		
	DMC-LS85	AA	BRAUN NiMH 2700		
	DMC-LX2	3,7V/1150mAh	BDP-S005E	B39	59237
	LX-3	3,7V/1150mAh	BDP-S005E	B39	59237
	DMC-LZ3ES	AA	BRAUN NiMH 2700		
	DMC-LZ5	AA	BRAUN NiMH 2700		
	DMC-LZ6	AA	BRAUN NiMH 2700		
	DMC-LZ7	AA	BRAUN NiMH 2700		
	DMC-LZ8	AA	BRAUN NiMH 2700		
	DMC-LZ10	AA	BRAUN NiMH 2700		
	DMC-SV-AV100	3,7V/1100mAh	BDP-NP60	B12	59211
	DMC-TZ1	3,7V/1000mAh	BDP-S007	B40	59238
	DMC-TZ2	3,7V/1000mAh	BDP-S007	B40	59238
	DMC-TZ3	3,7V/1000mAh	BDP-S007	B40	59238

<b>Panasonic</b>	DMC-TZ4	3,7V/1000mAh	BDP-S007	B40	59238
	DMC-TZ5	3,7V/1000mAh	BDP-S007	B40	59238
	DMC-TZ6	3,6V/895mAh	BDP-PBCG10	B160	59368
	DMC-TZ7	3,6V/895mAh	BDP-PBCG10	B160	59368
	DMC-TZ8 / TZ10	3,6V/895mAh	BDP-PBCG10	B160	59368
	DMC-ZX1	3,6V/895mAh	BDP-PBCG10	B160	59368
	DMC-ZX3	3,6V/895mAh	BDP-PBCG10	B160	59368

<b>Pentax</b>	*istDL	AA	BRAUN NiMH 2700		
	*istDL2	AA/CR-V3	BRAUN NiMH 2700		
	*istDs	AA	BRAUN NiMH 2700		
	*istD	AA	BRAUN NiMH 2700		
	K-m	AA	BRAUN NiMH 2700		
	K 7	7,4V/1400mAh	BDP-PDLI90	B163	59371
	K10D	7,4V/1300mAh	BDP-PLi50	B91	59301
	K10D GP	7,4V/1300mAh	BDP-PLi50	B91	59301
	K20D	7,4V/1300mAh	BDP-PLi50	B91	59301
	K100D	AA	BRAUN NiMH 2700		
	K100D Super	AA	BRAUN NiMH 2700		
	K110D	AA	BRAUN NiMH 2700		
	K200D	AA	BRAUN NiMH 2700		
	X 70	3,7V/925mAh	BDP-PDLI92	B162	59370
	Optio 30	AA	BRAUN NiMH 2700		
	Optio 50	AA	BRAUN NiMH 2700		
	Optio 50L	AA	BRAUN NiMH 2700		
	Optio 60	AA	BRAUN NiMH 2700		
	Optio 330	3,7V/1100mAh	BDP-FNP60	B12	59211
	Optio 430	3,7V/1100mAh	BDP-FNP60	B12	59211
	Optio 450	3,7V/1800mAh	BDP-FNP120	B123	59333
	Optio 550	3,7V/1800mAh	BDP-FNP120	B123	59333
	Optio 555	3,7V/1800mAh	BDP-FNP120	B123	59333
	Optio 750	3,7V/1800mAh	BDP-FNP120	B123	59333
	Optio 750Z	3,7V/1800mAh	BDP-FNP120	B123	59333
	Optio A10	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio A10	3,7V/680mAh	BDP-DLI85	B169	59377
	Optio A20	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio A30	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio A40	3,7V/1000mAh	BDP-PELI68	B118	59328
	Optio E10	AA	BRAUN NiMH 2700		
	Optio E20	AA	BRAUN NiMH 2700		
	Optio E30	AA	BRAUN NiMH 2700		
	Optio E40	AA	BRAUN NiMH 2700		
	Optio E50	AA	BRAUN NiMH 2700		
	Optio E60	AA	BRAUN NiMH 2700		
	Optio E65	3,7V/680mAh	BRAUN-PDLI88	B157	59366
	Optio E 70	AA	BRAUN NiMH 2700		
	Option E 75	3,7V/820 mAh	BDP-PELI95		
	Optio E 70L	AA	BRAUN NiMH 2700		
	Optio E 80	AA	BRAUN NiMH 2700		
	Optio E 85	3,7V/820 mAh	BDP-PELI95		

<b>Pentax</b>	<b>Option K-7</b>	<b>7,4V/1400mAh</b>	<b>BDP-PDLI90</b>	<b>B163</b>	<b>59371</b>
	Optio L20	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio L40	3,7V/740mAh	BDP-PELI63	B117	59327
	Optio L63	3,7V/740 mAh	BDP-PELI63	B42	59240
	Optio M10	AA	BRAUN NiMH 2700		
	Optio M20	AA	BRAUN NiMH 2700		
	Optio M30	3,7V/740mAh	BDP-PELI63	B117	59327
	Optio M40	3,7V/740mAh	BDP-PELI63	B117	59327
	Optio M50	3,7V/740mAh	BDP-PELI63	B117	59327
	Optio M60	3,7V/680mAh	BDP-PELI78	B119	59329
	<b>Option M85</b>	<b>3,7V/820 mAh</b>	<b>BDP-PELI95</b>		
<b>Pentax</b>	Optio MX	3,7V/1800mAh	BDP-FNP120	B123	59333
	Optio MX4	3,7V/1800mAh	BDP-FNP120	B123	59333
	Optio P70	3,7V/925mAh	BDP-PDLI92	B162	59370
	<b>Optio P80</b>	<b>3,7V/680mAh</b>	<b>BDP-PDLI88</b>	<b>B157</b>	<b>59366</b>
	Optio S	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio S4	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio S4i	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio S5i	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio S5n	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio S5z	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio S6	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio S7	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio S10	3,7V/1000mAh	BDP-PELI68	B118	59328
	Optio S12	3,7V/1000mAh	BDP-PELI68	B118	59328
	Optio S30	AA	BRAUN NiMH 2700		
	Optio S40	AA	BRAUN NiMH 2700		
	Optio S45	AA	BRAUN NiMH 2700		
	Optio S50	AA	BRAUN NiMH 2700		
	Optio S55	AA	BRAUN NiMH 2700		
	Optio S60	AA	BRAUN NiMH 2700		
	Optio SV	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio SVI	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio T10	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio T20	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio T30	3,7V/740mAh	BDP-PELI63	B117	59327
	Optio V10	3,7V/740mAh	BDP-PELI63	B117	59327
	Optio V20	3,7V/680mAh	BDP-PELI78	B119	59329
	Optio W10	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio W20	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio W30	3,7V/740mAh	BDP-PELI63	B117	59327
	Optio W60	3,7V/680mAh	BDP-PELI78	B119	59329
	Optio W80	3,7V/680mAh	BDP-PELI78	B119	59329
	Optio WP	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio Wpi	3,7V/750mAh	BDP-FNP40	B10	59209
	<b>Optio WS80</b>	<b>3,7V/680mAh</b>	<b>BDP-PDLI88</b>	<b>B157</b>	<b>59366</b>
	Optio X	3,7V/750mAh	BDP-FNP40	B10	59209
	Optio X70	3,7V/925mAh	BDP-PDLI92	B162	59370
	Optio Z10	3,7V/660mAh	BDP-PELI72	B120	59330

<b>Praktica</b>	DC 60	AA	BRAUN NiMH 2700		
	DC 52	3,7V/1100mAh	BDP-FNP60	B12	59211
	DCZ 5.4	AA	BRAUN NiMH 2700		
	DCZ 5.5	AA	BRAUN NiMH 2700		
	DCZ 5.8	AA	BRAUN NiMH 2700		
	DCZ 6.2	AA	BRAUN NiMH 2700		
	DCZ 6.3	AA	BRAUN NiMH 2700		
	DCZ 6.8	AA	BRAUN NiMH 2700		
	DCZ 7.2	AA	BRAUN NiMH 2700		

<b>Praktica</b>	DCZ 7.3	AA	BRAUN NiMH 2700		
	DCZ 7.4	AA	BRAUN NiMH 2700		
	DCZ 8.1	AA	BRAUN NiMH 2700		
	DCZ 8.2	AA	BRAUN NiMH 2700		
	DCZ 8.3	3,7V/720mAh	BDP-MNP900	B104	59314
	DCZ 10.1	AA	BRAUN NiMH 2700		
	DCZ 10.2	AA	BRAUN NiMH 2700		
	DCZ 10.3	3,7V/750mAh	BDP-FNP40	B10	59209
	DCZ 10.4	3,7V/720mAh	BDP-MNP900	B104	59314
	DCZ 12.1	AA	BRAUN NiMH 2700		
	Dpix 510Z	AA	BRAUN NiMH 2700		
	Dpix 530Z	AA	BRAUN NiMH 2700		
	Dpix 740Z	AA	BRAUN NiMH 2700		
	DPix 750Z	AA	BRAUN NiMH 2700		
	Dpix 820Z	AA	BRAUN NiMH 2700		
	Dpix 910Z	AA	BRAUN NiMH 2700		
	Dpix 1000Z	AA	BRAUN NiMH 2700		
	Dpix 1100Z	AA	BRAUN NiMH 2700		
	Dpix 3200	AAA	BRAUN NiMH 1000		
	Dpix 3300	AAA	BRAUN NiMH 1000		
	Dpix 5100	AA	BRAUN NiMH 2700		
	Dpix 5200	AA	BRAUN NiMH 2700		
	Dpix 9000	AA	BRAUN NiMH 2700		
	DVC 5.4FHD	3,7v/1800mAh	BDP-FNP120	B123	59333
	DVC 5.2FHD	3,7V/1100mAh	BDP-FNP60	B12	59211
	DVC 5.1HD	3,7v/1800mAh	BDP-FNP120	B123	59333
	DVC 6.1	3,7V/1100mAh	BDP-FNP60	B12	59211
	DVC 7.1Z	3,7V/1100mAh	BDP-FNP60	B12	59211
	HD 11.0i	3,7V/1100mAh	BDP-FNP60	B12	59211
	luxmedia 4008	AA	BRAUN NiMH 2700		
	luxmedia 5102	AA	BRAUN NiMH 2700		
	luxmedia 5103	AA	BRAUN NiMH 2700		
	luxmedia 5203	AA	BRAUN NiMH 2700		
	luxmedia 5303	AA	BRAUN NiMH 2700		
	luxmedia 6103	AA	BRAUN NiMH 2700		
	luxmedia 6105	3,7V/1100mAh	BDP-FNP60	B12	59211
	luxmedia 6403	3,7V/720mAh	BDP-MNP900	B104	59314
	luxmedia 6503	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 7103	3,7V/720mAh	BDP-MNP900	B104	59314

<b>Praktica</b>	luxmedia 7203	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 7303	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 7403	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 8003	AA	BRAUN NiMH 2700		
	luxmedia 8203	3,7V/720mAh	BDP-MNP900	B104	59314
	luxmedia 8213	3,7V/720mAh	BDP-MNP900	B104	59314
	luxmedia 8303	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 8403	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 8503	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 10-TS	3,7V/720mAh	BDP-KLIC7001	B25	59223

<b>Praktica</b>	luxmedia 12-03	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 12-TS	3,7V/720mAh	BDP-KLIC7001	B25	59223
	luxmedia 12-XS	3,7V/720mAh	BDP-MNP900	B104	59314
	luxmedia 10-XS	3,7V/720mAh	BDP-MNP900	B104	59314
	luxmedia 10-X3	AA	BRAUN NiMH 2700		
	luxmedia 10-03	3,7V/660mAh	BDP-FNP45	B95	59305
	luxmedia 10-23	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 12-HD	3,7V/750mAh	BDP-FNP40	B10	59209
	luxmedia 12-Z5	3,7V/660mAh	BDP-FNP45	B95	59305
	QD 500	AA	BRAUN NiMH 2700		
	QD 800	AA	BRAUN NiMH 2700		
	QD 900LCD	AA	BRAUN NiMH 2700		

<b>Ricoh</b>	<b>CX 1</b>	<b>3,7V/1000mAh</b>	<b>BDP-BCE10</b>	<b>B33</b>	<b>59231</b>
	CX 2	3,7V/1000mAh	BDP-BCE10	B33	59231
	Caplio 300G	AA	BRAUN NiMH 2700		
	Caplio 300G	3,7V/1100mAh	BDP-FNP60	B12	59211
	Caplio 300G	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio 400G Wide	AA	BRAUN NiMH 2700		
	Caplio 400G Wide	3,7V/1100mAh	BDP-FNP60	B12	59211
	Caplio 400G Wide	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio 500G	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio 500G Wide	AA	BRAUN NiMH 2700		
	Caplio 500SE	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio G3	3,7V/1100mAh	BDP-FNP60	B12	59211
	Caplio G3	3,7V/1800mAh	BDP-FNP120	B123	59333

<b>Ricoh</b>	Caplio G3S	3,7V/1100mAh	BDP-FNP60	B12	59211
	Caplio G3S	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio G4	3,7V/1100mAh	BDP-FNP60	B12	59211
	Caplio G4	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio G4wide	3,7V/1100mAh	BDP-FNP60	B12	59211
	Caplio G4wide	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio G 600	3,7V/1100mAh	BDP-FNP60	B12	59211
	Ricoh GR Digital	3,7V/1150mAh	BDP-FNP70	B15	59213
	Ricoh GR Digital II	3,7V/1150mAh	BDP-FNP70	B15	59213
	Ricoh GR Digital III	AAA	BRAUN NiMH 1000		

<b>Ricoh</b>	Caplio GX	AA	BRAUN NiMH 2700		
	Caplio GX	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio GX8	AA	BRAUN NiMH 2700		
	Caplio GX8	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio GX100	AA	BRAUN NiMH 2700		
	Caplio GX 200	3,7V/1100mAh	BDP-FNP60	B12	59211
	Caplio Pro G3	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio R1	AA	BRAUN NiMH 2700		
	Caplio R1V	AA	BRAUN NiMH 2700		
	Caplio R2	AA	BRAUN NiMH 2700		

<b>Ricoh</b>	Caplio R3	3,7V/1150mAh	BDP-S005E	B39	59237
	Caplio R4	3,7V/1150mAh	BDP-S005E	B39	59237
	Caplio R5	3,7V/1150mAh	BDP-S005E	B39	59237
	Caplio R6	3,7V/1000mAh	BDP-BCE10	B33	59231
	Caplio R7	3,7V/1000mAh	BDP-BCE10	B33	59231
	Caplio R8	3,7V/1000mAh	BDP-BCE10	B33	59231
	Caplio R10	3,7V/1000mAh	BDP-BCE10	B33	59231
	Caplio R30	3,7V/1150mAh	BDP-S005E	B39	59237
	Caplio R40	3,7V/1150mAh	BDP-S005E	B39	59237
	Caplio R50	3,7V/680mAh	BDP-PELI78	B119	59329
	Caplio RR10	3,7V/1100mAh	BDP-FNP60	B12	59211
	Caplio RR10	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio RR30	3,7V/1100mAh	BDP-FNP60	B12	59211
	Caplio RR30	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio RR230	AA	BRAUN NiMH 2700		
	Caplio RR330	AA	BRAUN NiMH 2700		
	Caplio RR330	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio RR530	AA	BRAUN NiMH 2700		
	Caplio RR630	AA	BRAUN NiMH 2700		
	Caplio RR660	AA	BRAUN NiMH 2700		
	Caplio RR730	AA	BRAUN NiMH 2700		
	Caplio RR750	AA	BRAUN NiMH 2700		
	Caplio RR770	AA	BRAUN NiMH 2700		
	Caplio RX	AA	BRAUN NiMH 2700		
	Caplio RX	3,7V/1800mAh	BDP-FNP120	B123	59333
	Caplio RZ1	AA	BRAUN NiMH 2700		
	Ricoh 500SE	AA	BRAUN NiMH 2700		

<b>Rollei</b>	Compactline 150	3,7V/1100mAh	BDP-FNP60	B12	59211
	Compactline 100	AA	BRAUN NiMH 2700		
	Compactline 80	AA	BRAUN NiMH 2700		
	RCP-6324	AA	BRAUN NiMH 2700		
	RCP-7324	AA	BRAUN NiMH 2700		
	RCP-7325XS	AA	BRAUN NiMH 2700		

<b>Rollei</b>	RCP-7330X	AA	BRAUN NiMH 2700		
	RCP-7430XW	3,7V/1100mAh	BDP-FNP60	B12	59211
	RCP-8325	3,7V/1100mAh	BDP-FNP60	B12	59211
	RCP-8325X	3,7V/1100mAh	BDP-FNP60	B12	59211
	RCP-8330X	AA	BRAUN NiMH 2700		
	RCP-8427XW	3,7V/1100mAh	BDP-FNP60	B12	59211
	RCP-10325X	3,7V/1100mAh	BDP-FNP60	B12	59211
	RCP-S8	AA	BRAUN NiMH 2700		
	RCP-S10	AA	BRAUN NiMH 2700		
	X8	AA	BRAUN NiMH 2700		

<b>Samsung</b>	D60	AA	BRAUN NiMH 2700		
	D70	AA	BRAUN NiMH 2700		
	D75	AA	BRAUN NiMH 2700		
	D860	AA	BRAUN NiMH 2700		
	ES-15	AA	BRAUN NiMH 2700		
	ES-20	AA	BRAUN NiMH 2700		
	ES-55	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	ES-60	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	ES-65		Not Available		
	ES-70		Not Available		
	GX 10	7,4V/1300mAh	BDP-PDLI50	B91	59301
	GX-1S	AA	BRAUN NiMH 2700		
	GX-1L	AA	BRAUN NiMH 2700		
	GX20	7,4V/1500mAh	BDP-PDLI50	B91	59301
	Pro815	7,4V/1900mAh	BDP-SLB1974	B50	59248
	Digimax i5	3,7V/820mAh	BDP-SLB0837	B41	59239
	Digimax i6 PMP	3,7V/820mAh	BDP-SLB0837	B41	59239
	i7	3,7V/750mAh	SLB-1137C		
	i8	3,7V/750mAh	BDP-SLB0937	B89	59298
	Digimax i50	3,7V/820mAh	BDP-SLB0837	B41	59239
	i70	3,7V/820mAh	BDP-SLB0837	B41	59239
	Digimax i73	3,7V/1100mAh	BDP-NP60	B12	59211
	Digimax i74wide	3,7V/1100mAh	BDP-NP60	B12	59211
	Digimax i85	3,7V/1100mAh	BDP-SLB1137D	B99	59309
	IT-100	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	Digimax L50	3,7V/820mAh	BDP-SLB0837	B41	59239
	Digimax L55	3,7V/820mAh	BDP-SLB0837	B41	59239
	Digimax L60	3,7V/820mAh	BDP-SLB0837	B41	59239
	L73	3,7V/820mAh	BDP-SLB0837	B41	59239
	L74 Wide	3,7V/1100mAh	BDP-NP60	B12	59211
	L77	3,7v/800mAh	BDP-SLB0837B	B92	59302
	L 83T	3,7V/820mAh	BDP-SLB0837	B41	59239
	Digimax L85	3,7V/1230mAh	BDP-SLB1237	B49	59247
	L100	3,7V/1050mAh	BDP-SLB10A	B98	59308
	L110	3,7V/1050mAh	BDP-SLB10A	B98	59308
	L200	3,7V/1050mAh	BDP-SLB10A	B98	59308
	L201	3,7v/800mAh	BDP-SLB0837B	B92	59302
	L210	3,7V/1050mAh	BDP-SLB10A	B98	59308

<b>Samsung</b>	L310W	3,7V/1050mAh	BDP-SLB10A	B98	59308
	L700	3,7V/820mAh	BDP-SLB0837	B41	59239
	L730	3,7V/750mAh	BDP-SLB0937	B89	59298
	L830	3,7V/750mAh	BDP-SLB0937	B89	59298
	M100	3,7V/1050mAh	BDP-SLB10A	B98	59308
	Digimax MP3	3,7V/820mAh	BDP-SLB0837	B41	59239
	NV3	3,7V/820mAh	BDP-SLB0837	B41	59239
	NV3 Special Ed.	3,7V/820mAh	BDP-SLB0837	B41	59239
	NV4	3,7V/750mAh	BDP-SLB0937	B89	59298
	NV7 OPS	3,7V/820mAh	BDP-SLB0837	B41	59239
	NV8	3,7V/820mAh	BDP-SLB0837	B41	59239
	NV 9	3,7V/1050mAh	BDP-SLB10A	B98	59308

<b>Samsung</b>	NV10	3,7V/820mAh	BDP-SLB0837	B41	59239
	NV 11	3,7V/1100mAh	BDP-NP60	B12	59211
	NV 15	3,7V/1100mAh	BDP-NP60	B12	59211
	NV 20	3,7V/1100mAh	BDP-NP60	B12	59211
	NV24HD	3,7V/1100mAh	BDP-SLB1137D	B99	59309
	NV30	3,7V/1100mAh	BDP-SLB1137D	B99	59309
	NV40	3,7V/1100mAh	BDP-SLB1137D	B99	59309
	NV 100HD	3,7V/1100mAh	BDP-SLB1137D	B99	59309
	NX10		BDP-SLB 1310		
	PL-50	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	PL-51	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	PL55	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	PL-60	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	PL-65	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	PL-70	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	PL-100		not Available		
	PL-150		not Available		
	S83	AA	BRAUN NiMH 2700		
	S85	AA	BRAUN NiMH 2700		
	S630	AA	BRAUN NiMH 2700		
	S730	AA	BRAUN NiMH 2700		
	S750	AA	BRAUN NiMH 2700		
	S760	AA	BRAUN NiMH 2700		
	S850	AA	BRAUN NiMH 2700		
	S860	AA	BRAUN NiMH 2700		
	S1050	AA	BRAUN NiMH 2700		
	S1060	AA	BRAUN NiMH 2700		
	S 1070	AA	BRAUN NiMH 2700		
	ST -45	3,7V/720mAh	BDP-SLB07A	B168	59376
	ST-50	3,7V/720mAh	BDP-SLB07A	B168	59376
	ST-500	3,7V/720mAh	BDP-SLB07A	B168	59376
	ST-550	3,7V/720mAh	BDP-SLB07A	B168	59376
	ST-1000	3,7V/1130mAh	SLB11A		
ST-5000	3,7V/1130mAh	SLB11A			
ST-5500	3,7V/1130mAh	SLB11A			
Digimax S500	AA	BRAUN NiMH 2700			

<b>Samsung</b>	Digimax S600	AA	BRAUN NiMH 2700		
	Digimax S700	AA	BRAUN NiMH 2700		
	Digimax S800	AA	BRAUN NiMH 2700		
	Digimax S1000	AA	BRAUN NiMH 2700		
	Digimax UC-A3	3,7V/1100mAh	BDP-NP60	B12	59211
	WB-500	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	WB-550	3,7V/1050mAh	BRAUN -SLB10A	B98	59308
	WB-1000	3,7V/1130mAh	SLB11A		
	<b>WB-5000</b>	<b>3,7V/1130mAh</b>	<b>SLB11A</b>		

<b>Sanyo</b>	XACTI VPC-A5	3,7V/660mAh	BDP-PELI72	B120	59330
	VPC-AZ3EX	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	VPC-HD700	3,7V/1200mAh	BDP-DBL40	B136	59344
	VPC-MZ3EX	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	VPC-J1	3,7V/1100mAh	BDP-LI10B/12B	B30	59228
	VPC-X1200	3,7V/700mAh	BDP-SDBL80	B153	59361
	XACTI DMX-HD1	3,7V/1200mAh	BDP-DBL40	B136	59344
	XACTI DMX-HD1A	3,7V/1200mAh	BDP-DBL40	B136	59344
	Xacti DMX-HD2	3,7V/1200mAh	BDP-DBL40	B136	59344
	Xacti DMX-HD800	3,7V/1200mAh	BDP-DBL40	B136	59344
	Xacti HD-1	3,7V/1200mAh	BDP-DBL40	B136	59344
	XACTI VPC-C6	3,7V/720mAh	BDP-DBL20	B51	59249
	XACTI VPC-E6	3,7V/720mAh	BDP-DBL20	B51	59249
	XACTI VPC-E7	3,7V/720mAh	BDP-DBL20	B51	59249
	XACTI VPC-E7EX	3,7V/720mAh	BDP-DBL20	B51	59249
	XACTI VPC-E10	3,7V/680mAh	BDP-PELI78	B119	59329
	XACTI VPC-E60	3,7V/720mAh	BDP-DBL20	B51	59249
	XACTI VPC-E875	3,7V/680mAh	BDP-PELI78	B119	59329
	XACTI VPC-E1075	3,7V/720mAh	BDP-DBL20	B51	59249
	XACTI VPC-E1090	3,7V/750mAh	BDP-NP40	B10	59209
	XACTI VPC-HD1	3,7V/1200mAh	BDP-DBL40	B136	59344
	XACTI VPC-HD1A	3,7V/1200mAh	BDP-DBL40	B136	59344
	XACTI VPC-H1EX	3,7V/1200mAh	BDP-DBL40	B136	59344
	XACTI VPC-HD2	3,7V/1200mAh	BDP-DBL40	B136	59344
	XACTI VPC-J4EX	3,7V/720mAh	BDP-DBL20	B51	59249
	XACTI VPC-S4	AA	BRAUN NiMH 2700		
	XACTI VPC-S5	AA	BRAUN NiMH 2700		
	XACTI VPC-S6	AA	BRAUN NiMH 2700		
	XACTI VPC-S7	AA	BRAUN NiMH 2700		
	XACTI VPC-S50	AA	BRAUN NiMH 2700		
	XACTI VPC-S60	AA	BRAUN NiMH 2700		
	XACTI VPC-S70	AA	BRAUN NiMH 2700		
	XACTI VPC-S760	AA	BRAUN NiMH 2700		
	XACTI VPC-S870	AA	BRAUN NiMH 2700		
	XACTI VPC-S1070	AA	BRAUN NiMH 2700		
	XACTI VPC-S1275	AA	BRAUN NiMH 2700		
	XACTI VPC-X1200	3,7V/680mAh	BDP-SDBL80	B153	59361

<b>Sony</b>	DSLR-Alpha 100	7,2V/1620mAh	BDP-NPFM55H	B52	59250
	DSLR-Alpha 100H	7,2V/1620mAh	BDP-NPFM55H	B52	59250
	DSLR-Alpha 100K	7,2V/1620mAh	BDP-NPFM55H	B52	59250
	DSLR-Alpha 100W	7,2V/1620mAh	BDP-NPFM55H	B52	59250
	DSLR-Alpha 200	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-Alpha 200K	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-Alpha 200W	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-A230	7,4V/800mAh	BDP-SFH50N	B138	59346
	DSLR-Alpha 300X	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-Alpha 300K	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-Alpha 300	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-A330	7,4V/800mAh	BDP-SFH50N	B138	59346
	DSLR-Alpha 350X	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-Alpha 350K	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-Alpha 350	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-A380	7,4V/800mAh	BDP-SFH50N	B138	59346
	DSLR-A450	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-A500	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-A550	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-Alpha 700P	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-Alpha 700K	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-Alpha 700	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-A850	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSLR-A900	7,2V/1650mAh	BDP-SFM500H	B100	59310
	DSC-G1	3,6V/1220mAh	BDP-FR1	B31	59229
	DSC-H3	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-H7	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-H9	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-H10	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-H20	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-H50	3,6V/960mAh	BDP-BG1	B47	59245
	<b>DSC-H55</b>	<b>3,6V/960mAh</b>	<b>BDP-BG1</b>	<b>B47</b>	<b>59245</b>
	DSC-HX1	7,4V/800mAh	BDP-SFH50N	B138	59346
	<b>DSC-HX5V</b>	<b>3,6V/960mAh</b>	<b>BDP-BG1</b>	<b>B47</b>	<b>59245</b>
	DSC-M2	3,6V/710mAh	BDP-FT1	B46	59244
	DSC-N1	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-N2	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-P100	3,6V/1220mAh	BDP-FR1	B31	59229
	DSC-P150	3,6V/1220mAh	BDP-FR1	B31	59229
	DSC-P200	3,6V/1220mAh	BDP-FR1	B31	59229
	DSC-L1	3,6V/710mAh	BDP-FT1	B46	59244
	DSC-S500	AA	BRAUN NiMH 2700		
	DSC-S600	AA	BRAUN NiMH 2700		
	DSC-S650	AA	BRAUN NiMH 2700		
	DSC-S730	AA	BRAUN NiMH 2700		
	DSC-S750	3,7V/970mAh	BDP-SBK1	B142	59350
	DSC-S800	AA	BRAUN NiMH 2700		
	DSC-S930	AA	BRAUN Alkaline Batterien		
	DSC-S950	3,7V/970mAh	BDP-SBK1	B142	59350

<b>Sony</b>	DSC-S980	3,7V/970mAh	BDP-SBK1	B142	59350
	DSC-T1	3,6V/710mAh	BDP-FT1	B46	59244
	DSC-T2	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-T3	3,6V/710mAh	BDP-FT1	B46	59244
	DSC-T5	3,6V/710mAh	BDP-FT1	B46	59244
	DSC-T7	3,6V/450mAh	BDP-FE1	B44	59242
	DSC-T9	3,6V/710mAh	BDP-FT1	B46	59244
	DSC-T10	3,6V/710mAh	BDP-FT1	B46	59244
	DSC-T20	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-T30	3,6V/1220mAh	BDP-FR1	B31	59229
	DSC-T33	3,6V/710mAh	BDP-FT1	B46	59244
	DSC-T50	3,6V/1220mAh	BDP-FR1	B31	59229
	DSC-T70	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-T77	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-T90	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-T100	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-T200	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-T300	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-T500	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-T700	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-T900	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-TX1	3,7V/1000mAh	BDP-BD1	B86	59295
	DSC-TX7		BDP-NPBN1		
	DSC-V3	3,6V/1220mAh	BDP-FR1	B31	59229
	DSC-W30	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W35	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W50	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W55	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W70	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W310		BDP-NPBN1		
	DSC-W320		BDP-NPBN1		
	DSC-W350 S		BDP-NPBN1		
	DSC-W370	3,7V/970mAh	BDP-SBK1	B142	59350
	DSC-W380		BDP-NPBN1		
	DSC-W80	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W80HDPR	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W90	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W100	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W110	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W120	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W130	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W150	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W170	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W180	3,7V/970mAh	BDP-SBK1	B142	59350
	DSC-W190	3,7V/970mAh	BDP-SBK1	B142	59350
	DSC-W200	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W210	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W215	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W220	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W230	3,6V/960mAh	BDP-BG1	B47	59245

<b>Sony</b>	DSC-W270	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W275	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W290	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W300	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-W310/320		BDP-NPBN1		
	DSC-W350		BDP-NPBN1		
	DSC-W370		BDP-NPBK1		
	DSC-W380		BDP-NPBN1		
	DSC-WX1	3,6V/960mAh	BDP-BG1	B47	59245
	DSC-5650	AA	BRAUN NiMH 2700		
DSC-5800	AA	BRAUN NiMH 2700			

<b>Traveler</b>	D-1	AA	BRAUN NiMH 2700		
	DC 5	AA	BRAUN NiMH 2700		
	DC 3000	AA	BRAUN NiMH 2700		
	DC 4000	AA	BRAUN NiMH 2700		
	DC 4300	AA	BRAUN NiMH 2700		
	DC 5080	3,7V/720mAh	BDP-MNP900	B104	59314
	DC 5300	3,7V/1100mAh	BDP-NP60	B12	59211
	DC 5600	AA	BRAUN NiMH 2700		
	DC 6300	3,7V/1100mAh	BDP-NP60	B12	59211
	DC 6800	AA	BRAUN NiMH 2700		
	DC 6900	AA	BRAUN NiMH 2700		
	DC 7900	AA	BRAUN NiMH 2700		
	DC8300	3,7V/1230mAh	BDP-CNP40	B53	59251
	DC 8500	3,7V/1230mAh	BDP-CNP40	B53	59251
	DC 8600	3,7V/1230mAh	BDP-CNP40	B53	59251
	DC-X5	3,7V/1230mAh	BDP-CNP40	B53	59251
	DC-XZ6	3,7V/1230mAh	BDP-CNP40	B53	59251
	HD-10X	3,7V/1100mAh	BDP-NP60	B12	59211
	Happy Smile	AA	BRAUN NiMH 2700		
	Slimline X 4	3,7V/720mAh	BDP-MNP900	B104	59314
	Slimline X 5	3,7V/720mAh	BDP-MNP900	B104	59314
	XS4	3,7V/740mAh	BDP-EN-EL10	B48	59246
	Super Slim X8	3,7V/740mAh	BDP-EN-EL10	B48	59246
	Super Slim XS8	3,7V/740mAh	BDP-EN-EL10	B48	59246
	Super Slim XS10	3,7V/740mAh	BDP-EN-EL10	B48	59246
	Super Slim XS70	3,7V/740mAh	BDP-EN-EL10	B48	59246
	Super Slim XS80	3,7V/740mAh	BDP-EN-EL10	B48	59246
	UW 8	3,7V/740mAh	BDP-EN-EL10	B48	59246

<b>Traveler</b>	Slimline X 6	3,7V/720mAh	BDP-MNP900	B104	59314
	SX 330z	AA	BRAUN NiMH 2700		
	SX 410z	AA	BRAUN NiMH 2700		
	XS 7	3,7V/720mAh	BDP-MNP900	B104	59314

<b>Toshiba</b>	PDR-2	CR123			
	PDR-5	CR123			
	PDR-2300	AA	BRAUN NiMH 2700		
	PDR-3300	AA	BRAUN NiMH 2700		
	PDR-5300	3,7V/1100mAh	BDP-NP60	B12	59211
	PDR-M1	AA	BRAUN NiMH 2700		
	PDR-M3	3,7V/2000mAh	BDP-FNP100	B122	59332
	PDR-M4	3,7V/1400mAh	BDP-FNP80	B121	59331
	PDR-M5	3,7V/1400mAh	BDP-FNP80	B121	59331
	PDR-M25	AA	BRAUN NiMH 2700		
	PDR-M60	AA	BRAUN NiMH 2700		
	PDR-M61	AA	BRAUN NiMH 2700		
	PDR-M65	AA	BRAUN NiMH 2700		

<b>Toshiba</b>	PDR-M70	3,7V/1400mAh	BDP-FNP80	B121	59331
	PDR-M71	AA	BRAUN NiMH 2700		
	PDR-M81	AA	BRAUN NiMH 2700		
	PDR-M700	AA	BRAUN NiMH 2700		
	PDR-T10	AA	BRAUN NiMH 2700		
	PDR-T20	3,7V/1100mAh	BDP-NP60	B12	59211
	PDR-T30	3,7V/1100mAh	BDP-NP60	B12	59211
	Camileo Pro	3,7V/1100mAh	BDP-NP60	B12	59211

<b>Yakumo</b>	Mega Image 34	3,7V/1100mAh	BDP-NP60	B12	59211
	Mega Image 35	AA	BRAUN NiMH 2700		
	Mega Image 37	3,7V/1100mAh	BDP-NP60	B12	59211
	Mega Image 45	AA	BRAUN NiMH 2700		
	Mega Image 47	3,7V/1100mAh	BDP-NP60	B12	59211
	Mega Image 47SL	AA	BRAUN NiMH 2700		
	Mega Image 47SX	AA	BRAUN NiMH 2700		
	Mega Image 55CX	AA	BRAUN NiMH 2700		
	Mega Image 57	AA	BRAUN NiMH 2700		
	Mega Image 57X	AA	BRAUN NiMH 2700		
	Mega Image 67X	AA	BRAUN NiMH 2700		
	Mega Image 84D	AA	BRAUN NiMH 2700		
	Mega Image 85D	AA	BRAUN NiMH 2700		
	Mega Image 410	AA	BRAUN NiMH 2700		
	Mega Image 610X	AA	BRAUN NiMH 2700		
	Mega Image 811X	3,7V/1100mAh	BDP-NP60	B12	59211
	Mega Image IV	AA	BRAUN NiMH 2700		
	Mega Image VI	AA	BRAUN NiMH 2700		
	Mega Image VII	AA	BRAUN NiMH 2700		
	Mega Image X	AA	BRAUN NiMH 2700		
	Mega Image XL	AA	BRAUN NiMH 2700		
	Mega Image XS	AA	BRAUN NiMH 2700		